



1 GET RID OF THE CREASES

The best way to get rid of creases is to use clothes steamer. You will need it only once.





3 USE THE SCREWDRIVER







5 INSTALL THE CORNICE

Install the cornice on to the brackets, with the help of the hooks

